

## Placement tips

Step 1 : Remove your zelliges from the boxes and mix them together. This way you get a wonderful color range.

Step 2 Soak your zelliges in a bucket of cold or lukewarm water for at least four hours. This way they absorb water and not the moisture from the glue.

Step 3 Dry your zelliges and apply flex glue to the wall and tile with a glue comb. You can play with the thickness of the adhesive so that tiles don't stick out too much. Work per half m<sup>2</sup> if possible.

Step 4 Place the tiles against the wall. This can be done with or without crosses. If you work with crosses, they should not be thicker than 1.5 mm. Crosses are recommended on a surface larger than 10 m<sup>2</sup>.

Step 5 Now add a water-repellent grout between the tiles.

Step 6 Remove the excess grout when everything is dry. Never use chemical products. Let everyone enjoy the beautiful result